

## Switches

To compliment your Communication System, Techcess supplies a range of switches. Please note that the list below is not exhaustive: if you are looking for a particular switch which is not shown – please ask! Switches from other manufacturers may also be available.

### Single Switches



#### Buddy Buttons

Ever popular, strong but sensitive single switch available in wide range of colours and designs. Auditory and tactile feedback. Press anywhere on top surface. Size: 6.3cm dia.x 1.8cm. Activating force: 100g outer edge; 200g centre.

- 57000 BUDDY BUTTON BOLDLY BLACK
- 57050 BUDDY BUTTON WINTER WHITE
- 57100 BUDDY BUTTON RACECAR RED
- 57200 BUDDY BUTTON GATOR GREEN
- 57300 BUDDY BUTTON PASSIONATE PURPLE
- 57400 BUDDY BUTTON BUBBLEGUM PINK
- 57500 BUDDY BUTTON BUTTERCUP YELLOW
- 57600 BUDDY BUTTON BLUEJAY BLUE
- 57710 BUDDY BUTTON POLKA DOT
- 57720 BUDDY BUTTON HAPPY
- 57730 BUDDY BUTTON BULLSEYE
- 57740 BUDDY BUTTON HANDS-ON
- 57800 UNDERCOVER BUDDY BUTTON
- 57810 UNDERCOVER REPLACEMENT STICKERS (4)



#### Big Buddy

Larger version of the popular Buddy Button with choice of 6 colours and designs. Size: 11.5cm dia.x 2.5cm. Activating force: 150g outside edge; 300g centre

- 56100 BIG BUDDY RAVING RED
- 56200 BIG BUDDY GRANNY GREEN
- 56500 BIG BUDDY YAHOO YELLOW
- 56600 BIG BUDDY PACIFIC BLUE
- 56620 BIG BUDDY HAPPY-GO-LUCKY
- 56640 BIG BUDDY HANDS-ON



#### Pillow Switch

Single switch activated by pressing on top foam surface. Suitable for head or cheek activation. Safety-pin and Velcro for easy fastening to a pillow or wheelchair cushion. Auditory and tactile feedback. Size: 8cm diam. x 2cm. Activating force 180g

- 58750 Tash Pillow Switch



**Soft Switch**

Single switch encased in foam with a removable and washable cover. Auditory and tactile feedback. Size: 8cm diameter x 4cm. Activating force: 600g.

**58200** Soft Red

**58201** Soft Green



**Microlight**

Single switch with tactile and auditory feedback. Activated by pressing on top surface with feather-like touch. Size: 4.5 x 1.3 x 2cm. Activating force: 10g.

**58500** Tash Microlight



**Trigger Switch**

Tash Trigger Switch is a waterproof and rugged single switch designed to meet needs of wheelchair users. Available in 5 colours. Size: 2.3cm x 2.3cm x 0.6cm. Activating force: 300g.

**55000** TRIGGER GREY

**55100** TRIGGER RED

**55200** TRIGGER GREEN

**55400** TRIGGER ORANGE

**55600** TRIGGER BLUE



**Grasp Switch**

Single switch, operated by gentle squeeze or pinch on foam padding. Size: 3.5cm dia x 14cm.

Activation force: 300g

**58650** Tash Grasp Switch



**Cap Switch**

Single Switch with auditory and tactile feedback. Activated by pressing anywhere on the top surface.  
 Size: 4.5cm dia x 1.5cm. Activating force 250g  
**58060** Tash Cap Switch



**Mini Cup Switch**

Single Switch with auditory and tactile feedback. Switch is encased in plastic cup and supplied with coloured stickers. Size: 2.5cm dia x 0.9cm. Activating force: 130g  
**58080** Tash Mini Cup Switch



**Access Switch, Medium (by Unlimiter)**

Single switch available in a choice of 4 colours. Press anywhere on top surface to activate. Removable clear plastic top allows symbols, photos to be inserted. Auditory and tactile feedback. Size: 6.5cm dia. x 2.3cm.  
**AS-R** Red  
**AS-B** Blue  
**AS-G** Green  
**AS-Y** Yellow



**Access Switch, Small (by Unlimiter)**

Single switch available in a choice of 4 colours. Press anywhere on top surface to activate. Removable clear plastic top allows symbols, photos to be inserted. Auditory and tactile feedback. Size: 2.6m dia. x 1.1cm.  
**AS-S-R** Red  
**AS-S-B** Blue  
**AS-S-G** Green  
**AS-S-Y** Yellow



**Wobble Switch**

Can be activated by fine or gross movement from any direction. Tactile & auditory feedback  
**WOB** Unlimiter Wobble Switch

**Multiple Switches**



**Wafer Switch**

Five membrane switches in one switch, each 5.6cm diameter, slightly recessed, giving four mouse movements and a left click. No auditory or tactile feedback. Size: 40 x 15 x 1.3cm. Activating force: 100g.  
**25318** Tash USB Wafer Switch (connects directly to USB port of PC, no interface required)  
**50180** Tash Wafer Switch (9 pin D female connector: requires switch interface)



**Star Switch**

Five membrane switches, each 5.6cm diameter and slightly recessed providing four directional mouse movements and left click. Supplied with five coloured stickers. Slight tactile and auditory feedback. Size: 23 x 23 x 1.3cm. Activating force: 150g.  
**25326** Tash USB Star Switch (connects directly to USB port of PC, no interface required)  
**50260** Tash Star Switch (9 pin D female connector: requires switch interface)



**Mini Joystick with Push**

Four directional movements are activated by moving the joystick in four directions – the left click by pressing on the top. Two tips included – one flexible rubber, the other hard plastic. Tactile and auditory feedback. Size: 3cm dia x 12cm. Activating force: joystick – 120g; push – 200g.  
**25320** Tash USB Mini Joystick with Push (connects directly to USB port of PC, no interface required)  
**50200** Tash mini Joystick with push (9 pin D female connector: requires switch interface)



#### **Joystick with Pad**

A large joystick with four positions/directions and a raised pad making the left click.  
A rugged switch with auditory & tactile feedback.

Size: 28 x 18 x 12cm. Activating force: 200g.

**25312** Tash USB Joystick with Pad (connects directly to USB port of PC, no interface required)

**50120** Tash Joystick with Pad (9 pin D female connector: requires switch interface)



#### **Penta Switch**

For people with fine motor skills and good targeting ability. Activated by pressing down on five small (0.5cm) button switches for 4 directional mouse movements and left click. Tactile and auditory feedback.

Size: 5cm dia x 1.3cm. Activating force: 120g.

**25324** Tash USB Penta Switch connects directly to USB port of PC, no interface required)

**50240** Tash Penta Switch (9 pin D female connector: switch interface required)